

DOWNLOAD INSTRUCTIONS FOR HYPERCOM T7 TERMINAL BUILT AT TENDERCARD™

*Note: Hypercom terminals require at least 512K memory to run TenderCard.
This download will replace program in terminal. Batch out terminal first!*

Step	Terminal Display	Action
1	SWIPE CUSTOMER CARD	Press [FUNCTION] 99 , then press ENTER
2	ENTER PASSWORD	Enter 028510 , press ENTER
3	PROGRAM FUNCTION	Enter 9 , then press ENTER
4	TYPE ?	Press 6 , ENTER
5	TYPE ? TRANSACTION COMPLETE	Press 2 , ENTER (If terminal prompts for Hosts, just press ENTER).
6	TYPE ? TRANSACTION COMPLETE	Press 1 , ENTER
7	TYPE ? TRANSACTION COMPLETE	Press [CANCEL]
8	CONFIGURE TERMINAL OR CALL HELP - CO	Place terminal into <i>Boot Mode</i> - Unplug the terminal and hold down [VOID] and [OFFLINE] keys while plugging it back in, and hold keys down until 2 beeps are heard.
9	CONFIGURE TERMINAL OR CALL HELP - FE	Press [FUNCTION] 98 , then ENTER
10	CORRECT YES OR NO?	Press ENTER
11	CONFIGURE TERMINAL OR CALL HELP - PE	Press [FUNCTION] 2 , ENTER
12	TERMINAL ID NUMBER 70000011	Enter <i>Download Terminal ID</i> provided by Tech; press ENTER
13	INIT. TELEPHONE NO	Enter 18663644967 ; press ENTER
14	NMS TELEPHONE NO.	Enter 18663644967 ; press ENTER
15	DIAL 0-TONE 1-PULSE 0	Press ENTER
16	PABX ACCESS CODE	Enter PBX code if needed, or leave blank; press ENTER
17	COUNTRY CODE B5	Press ENTER
18	EXIT, PRESS, 'CANCEL'	Press CANCEL
19	PLEASE INITIALIZE OR CALL HELP – PE	Press [FUNCTION] 92 , ENTER
20	PROGRAM LOAC CORRECT? YES OR NO	Press ENTER
21	PROGRAM LOAD CHECKING LINE	* If terminal displays *LINE BUSY, WAIT" – it means it can't detect a dial tone.
22	PROGRAM LOAD PAGE XXX	Terminal is downloading; average download time is 30 minutes (12 pages)
23	PLEASE INITIALIZE	Press [INITIALIZE] key – terminal dials in again to get parameters; this should only take a couple of minutes.