

INSTRUCTIONS TO DOWNLOAD TENDERCARD ON INGENICO ELITE TERMINALS

Always batch out terminal first!

Step	Terminal Display	Action
1	IDLE PROMPT	Press the ADMIN key
2	ENTER ADMIN PASSWORD	Enter the password (provided by credit card processor), then press ENTER .
3	1. CLERK MENU 2. BATCH MENU 3. SETUP MENU	Press F1 key until DOWNLOAD appears; enter the number corresponding to DOWNLOAD , then press ENTER
4	DOWNLOAD ZONTALK?	Press ENTER
5	1. DWNLOAD APP 2. REMOVE APP	Press 1
6	1. APPLICATION 2. NEW CFG 3. DEL CFG <i>*this display may vary slightly</i>	Press the number corresponding to NEW CFG (new download configuration). *If NEW CFG is not displayed, press the F1 key until NEW CFG is displayed, then press the number corresponding to it.
7	1. DIRECT 2. DIAL	Press 2
8	PHONE NUMBER:	Enter 18004307995 (add PBX code if necessary), then press ENTER
9	BAUD RATE:	Press 2 for 1200 baud rate
10	1. FULL 2. PARTIAL	Press 1 for FULL
11	ELITE MODEL	Enter ELITE ; press ENTER **The ADMIN key will switch numbers to letters.
12	APPLICATION NAME	Enter TC008 ; press ENTER
13	TERMINAL ID	Enter <i>Download Terminal ID</i> provided by Tech; press ENTER
14	...Dialing...	A receipt prints the download configuration
15	DOWNLOADING	As download completes, asterisks will replace dashes (***------), and a percentage will display. A 1200 baud rate download takes about 15 minutes.
16	DOWNLOAD DONE	Terminal will restart and a receipt prints App 53v4 Added, DOWNLOAD COMPLETE
17	TENDERCARD INITIALIZING	Wait...don't go anywhere!!
18	ADD ON 53 NAME	Enter a name, such as TNDRCARD or TCARD or GIFTCARD – this is the name that will display on the terminal's Add-On menu. **If a name is not entered, "53" will be the display on the add-on menu, so it's important to enter a name. The name cannot be changed unless the application is removed and re-downloaded.

Use the Yellow **CORR** key to backspace/delete
Use the blue **ADMIN** key to switch between Numeric/Alpha